# VGN-A62B/A72PB/A72PS1/A72PS2/A72S1/A72S2 VGN-A600/A600B/A600P/A690 VGN-A317M/A317S/A397XP

# **SERVICE MANUAL**

Ver 3 -2005A

**Revision History** 

| Area     | Model    | Line up     |               |
|----------|----------|-------------|---------------|
| Japanese | Japanese | VGN-A62B    |               |
|          |          | VGN-A72PB   |               |
|          |          | VGN-A72PS1* |               |
|          |          | VGN-A72PS2* |               |
|          |          | VGN-A72S1*  |               |
|          |          | VGN-A72S2*  |               |
| American | US       | VGN-A600*   | <u> </u>      |
|          | Canadian | VGN-A600B*  | <u> </u>      |
|          |          | VGN-A600P*  | <u> </u>      |
|          |          | VGN-A690    | <u> </u>      |
| European | AEP      | VGN-A317M   | <u></u>       |
| ·        | UK       | VGN-A317S   | <b>☆[MA]</b>  |
|          |          | VGN-A397XP  | <b>⚠</b> [MA] |
|          |          |             | 7             |
|          |          |             |               |

\*: CTO Model













- Design and specifications are subject to change without notice.
- 本機の仕様および外観は、改良のため予告なく変更 することがありますが、ご了承ください。

PERSONAL COMPUTER



# Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks

of Microsoft Corporation in the United States and other countries.

The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, AMD logo, AMD Duron and combinations thereof. 3DNow!, are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, HotSync, PalmModem, and Palm OS are resistered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrora, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners.

In this manual, the (TM) or (R) mark are not specified.

Caution Markings for Lithium/Ion Battery - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate.

Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- Overcharging, short circuiting, reverse charging, multilation or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

## **Service and Inspection Precautions**

## Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

### 2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the  $\triangle$  mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

# 3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

## 4. Inspect after completing service

After servicing, inspect to make sure that all

screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

### 5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

## 6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

#### ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE & SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

## **TABLE OF CONTENTS**

|          | <u>Section</u>                        | <u>Title</u>          | <u>Page</u> | <u>Section</u>               |
|----------|---------------------------------------|-----------------------|-------------|------------------------------|
|          | CHAPTER                               | R 1. SPECIFICATIONS   |             | LCD                          |
|          | 1-1. SPECI                            | FICATIONS             | 1-1         | L-1. LCD 17                  |
|          | 1-2. CTO Ir                           | nformation            | 1-3         | – Made                       |
|          | 1                                     |                       | 1-3         | L-2. LCD 17                  |
|          | 2                                     |                       | 1-3         | - Made                       |
|          | 3                                     |                       | 1-4         | Accessories                  |
|          | 4                                     |                       | 1-4         | A-1. Accesso                 |
| <u> </u> | <u> </u>                              |                       | 1-5         | A-2. Accesso                 |
|          | 6                                     |                       | 1-5         | DIP Switch .                 |
|          | L 7                                   |                       | 1-6         |                              |
|          |                                       |                       | (to 1-6)    |                              |
|          |                                       |                       |             | CHAPTER 5                    |
|          | CHAPTER                               | R 2. BLOCK DIAGRAM    |             | 5-1. The Barc                |
|          |                                       | A series              |             | 5-2. Replacing               |
|          | 2-2. Port Re                          | eplicator (VGP-PRAV)  | 2-2         | <ol> <li>Removing</li> </ol> |
|          |                                       |                       | (to 2-2)    | 2. Installing                |
|          | CHAPTER                               | R 3. FRAME HARNESS D  | DIAGRAM     |                              |
|          | 3-1. VGN-A                            | A series              | 3-1         | 1.15                         |
|          | 3-2. Port Re                          | eplicator (VGP-PRAV)  | 3-2         | Hi                           |
|          |                                       |                       | (to 3-2)    | "R                           |
|          | CHAPTER                               | R 4. EXPLODED VIEWS A | AND         | 変                            |
|          | · · · · · · · · · · · · · · · · · · · | PARTS LIST            |             | ^                            |
|          | Palmrest                              |                       |             | 4                            |
|          | P-1. Palmr                            | est                   | 4-2         |                              |
|          | Main Board                            |                       |             |                              |
|          | M-1. Main                             | Board                 | 4-4         |                              |
|          | Bottom                                |                       |             |                              |
|          | B-1. Botto                            | m                     | 4-6         |                              |
|          | Optical Driv                          | e                     |             |                              |

D-1. Optical Drive .......4-8

| Secti | <u>on</u>                  | <u>Title</u> |                    | <u>Page</u> |
|-------|----------------------------|--------------|--------------------|-------------|
| LCD   |                            |              |                    |             |
|       |                            | ob WHVC      | A (Clear Black LC  | D)          |
| L-    |                            |              |                    | ,           |
|       | -                          |              |                    |             |
| L-    | 2. LCD 17-iı               | ich WXGA     | + (Clear Black LCI | D)          |
|       | <ul> <li>Made b</li> </ul> | y AU         |                    | 4-12        |
| Acce  | essories                   | -            |                    |             |
| A-    | 1. Accessorie              | s            |                    | 4-14        |
| A-    | 2. Accessorie              | s            |                    | 4-16        |
| DI    | P Switch                   |              |                    | 4-17        |
|       |                            |              |                    | (to 4-17)   |
| CHA   | APTER 5.                   | OTHERS       | 8                  |             |
| 5-1   | The Barcod                 | e Label      |                    | 5-1         |
|       |                            |              |                    |             |
|       |                            |              |                    |             |
|       |                            |              |                    |             |
| 2.    | Installing th              | e CPU        |                    | 5-2         |
|       |                            |              |                    | (to 5-2)    |

History of the changes is shown as the "Revision History" at the end of this data.

変更履歴は,"Revision History"として, 本データ末に記載してあります。

# CHAPTER 1. SPECIFICATIONS

## 1-1. Specifications

|                        |                      |                      |                      | J   |                 |                      |
|------------------------|----------------------|----------------------|----------------------|---|-----------------|----------------------|
|                        | VGN-A72PB            | VGN-A62B             | VGN-A72PS1*          | VGN-A72PS2*   | VGN-A72S1*      | VGN-A72S2*           |
| CPU                    | PM/Do/760/2GHz       | PM/Do/740/1.73GHz    | *1)                  | -7  |                 | *1)                  |
| Graphic                | Mobility Radeon X600 | Mobility Radeon X600 | Mobility Radeon X600 | eon X600 Mobility Radeon X600 Mobility Radeon X600 Mc |                 | Mobility Radeon X600 |
| CD                     | 17.0"WUXGA"          | 17.0/WXGA+           | 17.0"WUXGA"          | 17.0"WXGA+"   | 17.0"WUXGA"     | 17.0"WXGA+"          |
|                        | (Clear Black)        | (Clear Black)        | (Clear Black)        | (Clear Black)   | (Clear Black)   | (Clear Black)        |
| HDD                    | 100GB                | 100GB                | *2)                  | *2)   | *2)             | *2)                  |
| Memory                 | 512MB/DDR2/400*1     | 512MB/DDR2/400*1     | *3)                  | *3)   | *3)             | *3)                  |
| QUANTITY(STANDARD/MAX) | 512MB/2GB            | 512MB/2GB            |                      |   |                 |                      |
| OPT-DRIVE              | DVD Multi Drive      | DVD Multi Drive      | DVD Multi Drive      | DVD Multi Drive                                       | DVD Multi Drive | DVD Multi Drive      |
|                        | -                    | -                    | Combo                | Combo   | Combo           | Combo                |
| AC ADAPTOR             | AC19V7               | AC19V7               | AC19V7/AC19V10       | AC19V7/AC19V10  | AC19V7/AC19V10  | AC19V7/AC19V10       |
| BATTERY                | BP2EA                | BP2EA                | BP2EA                | BP2EA   | BP2EA           | BP2EA                |
| Wireless LAN           | 802.11a/b/g          | 802.11b/g            | 802.11a/b/g          | 802.11a/b/g   | 802.11a/b/g     | 802.11a/b/g          |
| Bluetooth              | X                    | X                    | X                    | X   | X               | X                    |
| AV PR                  | 0                    | 0                    | ○/X                  | ○/X   | ○/X             | ○/X                  |
| Audio PR               | X                    | X                    | X                    | X   | X               | X                    |
| W-Mouse                | 0                    | 0                    | 0                    | 0   | 0               | 0                    |
| Memory Card Adapter    | 0                    | 0                    | 0                    | 0   | 0               | 0                    |
| Remote Controller      | 0                    | 0                    | O/X                  | ○/X   | ○/X             | O/X                  |
| os                     | XP Pro               | XP Home              | XP Pro               | XP Pro  | XP Home         | XP Home              |

<sup>\*1)</sup>PM/Do/770/2.13GHz,PM/Do/750/1.86GHz,PM/Do/730/1.60GHz,CeIM/Do/360/1.40GHz

<sup>\*3)1</sup>GB\*2,512MB\*2,256MB\*2

|                        |                      | Α                            | M  | VGN-A600*                    |
|------------------------|----------------------|------------------------------|--|------------------------------|
|                        | VGN-A690             | VGN-A600P*                   | VGN-600B*  | VGN-A600*                    |
| CPU                    | PM/Do/750/1.86GHz    | *4)                          | *4)  | *4)                          |
| Graphic                | Mobility Radeon X600 | Mobility Radeon X600         | Mobility Radeon X600   | Mobility Radeon X600         |
| LCD                    | 17.0"WUXGA"          | 17.0"WUXGA"/17.0"WXGA+"      | 17.0"WUXGA2/17.0"WXGA+"  | 17.0"WUXGA"/17.0"WXGA+"      |
|                        | (Clear Black)        | (Clear Black)                | (Clear Black)  | (Clear Black)                |
| HDD                    | 100GB                | *5)                          | *5)  | *5)                          |
| Memory                 | 512MB/DDR2/400*2     | *6)                          | *4) *4) *4) *4) *4) *4) *4) *4) *A *4) *4) *A *4) * | *6)                          |
| QUANTITY(STANDARD/MAX) | 512MB/2GB            |                              |  |                              |
| OPT-DRIVE              | DVD+/-RW             | DVD+/-RW                     | DVD+/-RW   | DVD+/-RW                     |
|                        | -                    | Combo                        | Combo  | Combo                        |
| AC ADAPTOR             | AC19V7               | AC19V7/AC19V10               | AC19V7/AC19V10   | AC19V7/AC19V10               |
| BATTERY                | BP2EA                | BP2EA                        | BP2EA  | BP2EA                        |
| Wireless LAN           | 802.11a/b/g          | 802.11a/b/g,802.11b/g(Intel) | 802.11a/b/g,802.11b/g(Intel)   | 802.11a/b/g,802.11b/g(Intel) |
| Bluetooth              | Х                    | ○/X                          | ○/X  | ○/X                          |
| AV PR                  | 0                    | ○/X                          | ○/X  | ○/X                          |
| Audio PR               | Х                    | X                            | X  | X                            |
| W-Mouse                | х                    | ○/X                          | ○/X  | ○/X                          |
| Memory Card Adapter    | X                    | X                            | X  | X                            |
| Remote Controller      | 0                    | ○/X                          | ○/X  | ○/X                          |
| os                     | XP Home              | XP Pro                       | XP Pro(SMB)  | XP Home                      |
|                        |                      |                              |  | . A [MA]                     |

MA] \*4)PM/Do/770/2.13GHz,PM/Do/760/2GHz,PM/Do/750/1.86GHz,PM/Do/740/1.73GHz,PM/Do/730/1.60GHz,CelM/Do/360/1.40GHz

∑[MA] \*5)100GB,80GB,60GB,40GB

**⚠[MA]** \*6)1GB\*2,1GB\*1,512MB\*2,512MB\*1,256MB\*2,256MB\*1

- The trademarks or registered trademarks of above table, refer to page 2.
- The model that is accompanied by asterisk (\*) is the CTO model For the equipment configuration, refer to the CTO Information.
- 本表中の商標・登録商標については、2ページをご参照ください。
- 機種名に(\*)がつくのはCTOモデルです。

組み合わせについては、CTO Information ご確認ください。


<sup>\*2)100</sup>GB,80GB,60GB

|                        |                      | EU                   |                      |  |
|------------------------|----------------------|----------------------|----------------------|--|
|                        | VGN-A397XP           | VGN-A317S            | VGN-A317M            |  |
| CPU                    | PM/Do/760/2GHz       | PM/Do/750/1.86GHz    | PM/Do/740/1.73GHz    |  |
| Graphic                | Mobility Radeon X600 | Mobility Radeon X600 | Mobility Radeon X600 |  |
| LCD                    | 17.0"WUXGA"          | 17.0"WXGA+"          | 17.0"WXGA+"          |  |
|                        | (Clear Black)        | (Clear Black)        | (Clear Black)        |  |
| HDD                    | 80GB                 | 100GB                | 80GB                 |  |
| Memory                 | 512MB/DDR2/400*1     | 256MB/DDR2/400*2     | 256MB/DDR2/400*2     |  |
| QUANTITY(STANDARD/MAX) | 512MB/2GB            | 256MB/2GB            | 256MB/2GB            |  |
| OPT-DRIVE              | DVD+/-RW             | DVD+/-RW             | DVD+/-RW             |  |
|                        | -                    |                      |                      |  |
| AC ADAPTOR             | AC19V10              | AC19V7               | AC19V10              |  |
| BATTERY                | BP2EA                | BP2EA                | BP2EA                |  |
| Wireless LAN           | 802.11b/g            | 802.11b/g            | 802.11b/g            |  |
| Bluetooth              | 0                    | 0                    | 0                    |  |
| AV PR                  | X                    | 0                    | x                    |  |
| Audio PR               | X                    | X                    | X                    |  |
| W-Mouse                | 0                    | 0                    | 0                    |  |
| Memory Card Adapter    | X                    | X                    | X                    |  |
| Remote Controller      | X                    | 0                    | X                    |  |
| os                     | XP Pro               | XP Home              | XP Home              |  |

 $\triangle$ [MA]  $\triangle$ [MA]


## 1-2. CTO Information

1. Model name:PCG-8S1N Model number:VGN-A72PS1 Product Code: Serial number:




2. Model name:PCG-8S1N Model number:VGN-A72PS2 Product Code:


Serial number: OS:Windows XP Pro Ver.1.0



#### 3. Model name:PCG-8S1N Model number:VGN-A72S1 Product Code: Serial number: os:Windows XP Home




#### 4. Model name:PCG-8S1N Model number:VGN-A72S2 Product Code: Serial number: OS:Windows XP Home



## Model name:PCG-8S1L,PCG-8S2L,PCG-8S3L,PCG-8S4L,PCG-8S5L,PCG-8S6L Model number:VGN-A600P


Ver.1.0

OS:Windows XP Pro



#### Model name:PCG-8S1L,PCG-8S2L,PCG-8S3L,PCG-8S4L,PCG-8S5L,PCG-8S6L


Model number:VGN-A600B OS:Windows XP Pro(SMB) Ver.1.0



## 7. Model name:PCG-8S1L,PCG-8S2L,PCG-8S3L,PCG-8S4L,PCG-8S5L,PCG-8S6L


Model number:VGN-A600 OS:Windows XP Home

Ver 1 0




# CHAPTER 2. BLOCK DIAGRAM

## 2-1. VGN-A series



## 2-2. Port Replicator (VGP-PRAV)




# CHAPTER 3. FRAME HARNESS DIAGRAM

#### ANTENNA ANTENNA LCD Block LCD 3-1. VGN-A series Aux Main (Black) SWX-185 BOARD Speaker I Speaker B $\Box$ $\Box$ VIDEO (Side-B) MONITOR OUT NETWORK USB USB DC-IN **Rear Panel** o[....]o KB LED DC FAN CN1401 EXTERNAL CN5103 CN1402 CN2202 CN1703 CN1702 MICROPHONE HEADPHONE ( CN510 CN3500 CPU CN5104 i.S400 USB DDR SO-DIMM **MBX-128 BOARD** PHONE (Side-A) **CNX-280 BOARD** سكسسسا SLOT B L Side (Side-A) MODEM RAM CARD NICKEL SLOT A R Side HYDROGEN BATTERY DDR SO-DIMM OPTICAL DRIVE PC CARD CN601 CONNECTOR IFX-378 BLUETOOTH 29 30 2 CN2701 4 1 CN180 BOARD MODULE CNX-289 BT ANTENNA (Side-A) CN2904 CN2702 (Bluetooth Model) **BOARD** USB RF MOUSE Aux (Black) RECEIVER TOUCH PAD Main (White) (Wireless-Mouse Model) Front MEMORY STICK ODD EJECT SWITCH BATTERY PACK CNX-290 KEY BOARD WIRELESS LAN **BOARD** CARD (Side-A) HARD DISK From board to connector (direct connection) Harness (connector at both end) Harness (soldered at one end)

Connectors soldered on board and appearing on the panel

## 3-2. Port Replicator (VGP-PRAV)



## CHAPTER 4.

## **EXPLODED VIEWS AND PARTS LIST**

 The parts list is compiled by blocks of a palmrest and bottom etc. The sections of the parts list are different depending on the model. Please refer to list of contents shown in the below.

| ●分解図と部品表は、パームレスト、ボトムなどのブロックご |
|------------------------------|
| とに分かれています。機種によって部品表のセクションが   |
| 異なりますので,詳細は右下の一覧表を参照してください。  |

| Section            | <u>Page</u> |
|--------------------|-------------|
| Palmrest           |             |
| P-1. Palmrest      | 4-2         |
| Main Board         |             |
| M-1. Main Board    | 4-4         |
| Bottom             |             |
| B-1. Bottom        | 4-6         |
| Optical Drive      |             |
| D-1. Optical Drive | 4-8         |
|                    |             |

| Section                                  | Page |
|--|------|
| LCD                                      |      |
| L-1. LCD 17-inch WUXGA (Clear Black LCD) | )    |
| - Made by SH                             | 4-10 |
| L-2. LCD 17-inch WXGA+ (Clear Black LCD) |      |
| - Made by AU                             | 4-12 |
| Accessories                              |      |
| A-1. Accessories                         | 4-14 |
| A-2. Accessories                         | 4-15 |
| DIP Switch                               | 4-17 |

#### NOTE:

- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
  The parts marked "#" are the parts on which
- The parts marked "#" are the parts on which barcode label is attached.

For the barcode label, refer to CHAPTER 5.

- The parts marked "&" are the "Customer Replacable Parts (CRP)" that can be replaced by Field Customer Support. Especially the parts with the <&> mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replaceable Parts(CRP), or the non-targetted parts by referring to the exploded view.
- Regarding the boards of this model, the discrete parts on the boards cannot be replaced. However, Some connectors can be replaced.
- The model that is accompanied by asterisk (\*) is the CTO model.

For the equipment configuration, refer to the CTO Information.

The components identified by mark  $\Delta$  or dotted line with mark  $\Delta$  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  $ext{$\Delta$}$  sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.


#### 【使用上の注意】

- \* 印の部品は常備在庫しておりません。
- 図面番号のない部品は供給しません。
- 併記部品の場合,上部記載部品をメイン部品として使用してください。
- 部品名称の前に\$印のついた部品は、High Value Module (HVM)です。
- 商品名称の前に#印のついた部品は、バーコードラベル貼付部品です。

バーコードラベルについてはCHAPTER5を参照してください。

- 部品名称の前に&印のついた部品は、お客様窓口などでも 交換可能な Customer Replacable Parts (CRP)です。 特に<</li>
   特に
- で、分解図で Customer Replacable Parts 対象部品か、対象 外部品かを必ず御確認ください。
- 本モデルの基板については、基板上の各部品の修理は行う ことができません。ただし、一部のコネクタについては、 修理可能です。
- 機種名に(\*)がつくのはCTOモデルです。
   組み合わせについては、CTO Informationを御確認ください。

△印の部品,または△印付きの点線で囲まれた部品は,安全性を維持するために重要な部品です。従って 交換時は,必ず指定の部品を使用してください。



|    |         | Palmrest | Main Board | Bottom | Optical Drive | LCD     | Accessories | Port Replicator | 1            |
|----|---------|----------|------------|--------|---------------|---------|-------------|-----------------|--------------|
|    | A72PB   | P-1      | M-1        | B-1    | D-1           | L-1     | A-1         | A-2 (J-PR)      | 1            |
|    | A62B    | P-1      | M-1        | B-1    | D-1           | L-2     | A-1         | A-2 (J-PR)      | 1            |
| J  | A72PS1* | P-1      | M-1        | B-1    | D-1           | L-1     | A-1         | A-2 (J-PR)      | 1            |
|    | A72S1*  | P-1      | M-1        | B-1    | D-1           | L-1     | A-1         | A-2 (J-PR)      | 1            |
|    | A72PS2* | P-1      | M-1        | B-1    | D-1           | L-2     | A-1         | A-2 (J-PR)      | 1            |
|    | A72S2*  | P-1      | M-1        | B-1    | D-1           | L-2     | A-1         | A-2 (J-PR)      | 1            |
|    | A690    | P-1      | M-1        | B-1    | D-1           | L-1     | A-1         | A-2 (U-PR)      | <u> </u>     |
| AM | A600P*  | P-1      | M-1        | B-1    | D-1           | L-1/L-2 | A-1         | A-2 (U-PR)      | <u> </u>     |
|    | A600B*  | P-1      | M-1        | B-1    | D-1           | L-1/L-2 | A-1         | A-2 (U-PR)      | <u> </u>     |
|    | A600*   | P-1      | M-1        | B-1    | D-1           | L-1/L-2 | A-1         | A-2 (U-PR)      | <u> </u>     |
|    | A397XP  | P-1      | M-1        | B-1    | D-1           | L-1     | A-1         |                 | <u></u> [MA] |
| EU | A317S   | P-1      | M-1        | B-1    | D-1           | L-2     | A-1         | A-2 (E-PR)      | <u></u>      |
|    | A317M   | P-1      | M-1        | B-1    | D-1           | L-2     | A-1         |                 | <u></u>      |
|    |         |          |            |        |               |         |             |                 | 1            |
|    |         |          |            |        |               |         |             |                 | 1            |
|    |         |          |            |        |               |         |             |                 |              |

\* : CTO Model


Confidential

VGN-A62B/A72PB/A72PS1/A72PS2/A72S1/A72S2 (J)

VGN-A600/A600B/A600P/A690 (AM)

VGN-A317M/A317S/A397XP (EU)

## P-1. Palmrest




## P-1. Palmrest

| Ref.No. | Part No.        | <u>Description</u>             |
|---------|-----------------|--------------------------------|
| 1       | A-1067-956-A    | ASSY SPEAKER                   |
| 2       | A-1058-413-A    | CABLE(20P), FLEXIBLE FLAT      |
| 3       | A-1058-417-A    | CABLE, KB LED                  |
| 4       | A-1094-548-A \$ | COMPLETE PWB SWX-185           |
| 6       | X-4626-655-2    | SE1P PALMREST ASSY             |
| 7       | 4-682-423-01    | SE1 SPONGE BT                  |
| 8       | 2-159-644-01    | SE1P SHEET SPEAKER RING        |
| 9       | 4-682-556-01    | SE1P SPEAKER BRACKET           |
| 10      | X-4626-657-1    | SE1P TP BKT ASSY               |
| 11      | 4-682-560-01    | TOUCHPAD SHEET                 |
| 12      | 2-103-688-01    | SE1P TOUCHPAD GASKET           |
| 14      | 1-866-586-11    | PWB(10P),FLEXIBLE PRINT        |
| 15      | A-1058-428-A    | PWB(10P),FLEXIBLE PRINT        |
| 16      | 1-796-911-12    | WIDE TOUCH PAD                 |
| 17      | 2-103-691-01    | SE1P BATT MASK MYLAR A         |
| 18      | 2-103-689-01    | SE1P KEYBOARD BRACKET MYLAR A  |
| 19      | 2-103-690-01    | SE1P KEYBOARD BRACKET MYLAR B  |
| 20      | 2-103-692-01    | SE1P PALMREST GASKET           |
| 21      | 2-159-642-01    | SE1P LED PORON                 |
| 22      | 2-159-643-01    | SE1P KEYBOARD SUPPORT MYLAR    |
| 23      | 2-159-977-01    | SE1P KEYBOARD SUPPORT MYLAR B  |
| 24      | 2-548-305-01    | SE1 MYLAR SPEAKER BKT          |
| B2      | 4-672-836-21    | SCREW, M2 SPECIAL HEAD,EG GRIP |
| B4      | 2-048-596-02    | SCREW, +B EG GRIP              |
| B5      | 4-672-836-11    | SCREW, M2 SPECIAL HEAD,EG GRIP |

|      |                                   |   |                    |       |      | J       |        |         |        |      | Α      | M      |       |        | EU    |       | <u> </u> |
|------|-----------------------------------|---|--------------------|-------|------|---------|--------|---------|--------|------|--------|--------|-------|--------|-------|-------|----------|
|      | Ref.No. Part No.                  |   | Description        | A72PB | A62B | A72PS1* | A72S1* | A72PS2* | A72S2* | A690 | A600P* | A600B* | *009¥ | A397XP | A317S | A317M |          |
|      | 5 1-478-650-11                    | & | KEYBOARD UNIT (JP) | •     | •    | •       | •      | •       | •      | -    |        |        |       |        |       |       |          |
| [MA] | 1-478-650-21                      | & | KEYBOARD UNIT (US) |       |      |         |        |         |        | •    | •      | •      | •     |        |       |       |          |
| [MA] | 1-478-640-11                      | & | KEYBOARD UNIT (GB) |       |      |         | $\neg$ |         |        |      |        |        |       | •      | •     | •     |          |
| [MA] | 1-478-640-21                      | & | KEYBOARD UNIT (DE) |       |      |         |        |         |        |      |        |        |       | •      | •     | •     |          |
| [MA] | 1-478-640-31                      | & | KEYBOARD UNIT (CH) |       |      |         |        |         |        |      |        |        |       |        | •     | •     |          |
| [MA] | 1-478-640-41                      | & | KEYBOARD UNIT (FR) |       |      |         |        |         |        |      |        |        |       | •      | •     | •     |          |
| [MA] | 1-478-640-51                      | & | KEYBOARD UNIT (IT) |       |      |         |        |         |        |      |        |        |       | •      | •     | •     |          |
| [MA] | 1-478-640-61                      | & | KEYBOARD UNIT (ES) |       |      |         |        |         |        |      |        |        |       | •      | •     | •     |          |
| [MA] | 1-478-640-71                      | & | KEYBOARD UNIT (SE) |       |      |         |        |         |        |      |        |        |       | •      |       |       |          |
| [MA] | 1-478-640-81                      | & | KEYBOARD UNIT (PT) |       |      |         |        |         |        |      |        |        |       | •      |       |       |          |
| [MA] | B39 4-681-432-11                  |   | SCREW (M2) (SPIN)  |       |      |         |        |         |        | •    | •      | •      | •     |        |       |       |          |
|      | This parts list contains two diff |   |                    |       |      |         | •      |         |        | MA]  | [MA]   | [MA]   | [MA]  | [MA]   | [MA]  | [MA]≫ |          |

- The first type is the parts that are common to all models.
  The other type is the parts that are different depending on each model.

   This model that is accompanied by asterisk (\*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(\*)がつくのは CTO モデルです。




## M-1. Main Board

| Ref.No.    | Part No.                          | <u>Description</u>                  |
|------------|-----------------------------------|-------------------------------------|
| 301<br>304 | A-1058-426-A<br>A-1094-547-A \$ # | CABLE, RJ11<br>COMPLETE PWB MBX-128 |
| 305        | 4-682-945-01                      | SE1 2ND FAN MYLAR                   |
| 306        | X-2022-962-2                      | SE1 DC JACK HOLDER ASSY             |
| 307        | 4-682-478-01                      | SE1 ODD INSULATOR                   |
|            |                                   |                                     |
| 308        | 2-583-809-01                      | RH MYLAR CARD BUS                   |
| 309        | 4-682-475-01                      | SE1 SHEET MINI-PCI                  |
| 310        | 4-682-569-01                      | SE1P CARD BOX BRACKET               |
| 311        | X-4626-661-1                      | SE1P IO BRACKET ASSY                |
| 312        | 1-756-038-11                      | BATTERY, NICKEL HYDROGEN            |
| 313        | 4-642-711-11                      | SHEET (BATTERY), ADHESIVE           |
| 314        | 4-668-307-01                      | SHEET DIMM                          |
| 315        | A-1058-414-A                      | HARNESS.DC                          |
| 316        | 1-819-065-11                      | CONNECTOR.PC CARD                   |
| 317        | A-1094-416-A                      | RH FIN THERMAL MODULE               |
|            |                                   |                                     |
| 318        | A-1098-807-A \$                   | RH THERMAL MODULE                   |
| 319        | 2-583-808-01                      | RH VGA THERMAL PAD                  |
| 321        | 1-417-539-11 #                    | CARD,MODEM                          |
| 322        | 4-682-465-02                      | SE1 MYLAR DOOR DIMM                 |
| 323        | 2-103-444-01                      | SE1 EMI SPRING FIN                  |
| 004        | V 0000 000 4                      | OF4 FAILODDING DATE 4 ACCV          |
| 324        | X-2022-963-1                      | SE1 EMI SPRING BATT-1 ASSY          |
| 326<br>327 | 4-683-063-01<br>2-176-527-01      | RJ11 BKT<br>2ND FAN MYLAR-1         |
| 327        | 2-176-527-01                      | CPU THERMAL PAD                     |
| 329        | 2-103-452-01                      | SE1P THERMAL MODULE GASKET          |
| 329        | 2-103-093-01                      | SETF THERIMAL MODULE GASKET         |
| 331        | 2-583-810-01                      | RH MYLAR BOARD MAIN SHIELD          |
| 332        | 2-582-419-01                      | RH MYLAR CHIP                       |
|            |                                   |                                     |
| B1         | 4-672-836-01                      | SCREW, M2 SPECIAL HEAD,EG GRIP      |
| B3         | 4-672-834-41                      | SCREW, +B EG GRIP                   |
| B4         | 2-048-596-02                      | SCREW, +B EG GRIP                   |
| B5         | 4-672-836-11                      | SCREW, M2 SPECIAL HEAD,EG GRIP      |
| B6         | 4-656-703-01                      | SCREW, M2                           |
| B13        | 2-103-443-01                      | SE1 HEX2-5+7                        |
| B14        | 4-635-966-01                      | SCREW(HEX)                          |
| B40        | 4-672-834-01                      | SCREW, +B EG GRIP                   |
| D-10       | . 5.2 554 51                      | 33, 15 La aim                       |


|     |        |                             |   |  |            |      |         | J      |         |        |      | Α      | M      |       |        | EU    |       |   |               |
|-----|--------|-----------------------------|---|--|------------|------|---------|--------|---------|--------|------|--------|--------|-------|--------|-------|-------|---|---------------|
|     | D. (N. | Dord No.                    |   | D. and Co.                                   | A72PB      | A62B | A72PS1* | A72S1* | A72PS2* | A72S2* | A690 | A600P* | A600B* | A600* | A397XP | A317S | A317M |   |               |
| ŀ   | 302    | o. Part No.<br>6-707-260-01 |   | Description IC RH80536GE0412MSL7SM(PM-DO2.0) | -          |      |         |        | _       | _      |      |        |        |       | _      |       | -     | - | $\dashv$      |
| - 1 | 302    | 6-707-258-01                |   | IC RH80536GE0302MSL7SM(PM-DO2.0)             | <b>_</b> _ | •    |         |        |         | _      |      | •      | •      | -     | _      |       | •     | _ | $\rightarrow$ |
|     |        |                             |   |  |            | •    |         |        |         |        |      | •      | •      | •     |        |       | •     |   |               |
|     |        | 6-707-261-01                |   | IC RH80536GE0462MSL7SL(PM-DO 2.13)           |            |      | •       | •      | •       | •      |      | •      | •      | •     |        |       |       |   |               |
|     |        | 6-707-259-01                |   | IC RH80536GE0362MSL7S9(PM-DO1.86)            |            |      | •       | •      | •       | •      | •    | •      | •      | •     |        | •     |       |   |               |
|     |        | 6-707-252-01                |   | IC RH80536GE0252MSL86G(PM-DO 1.60)           |            |      | •       | •      | •       | •      |      | •      | •      | •     |        |       |       |   |               |
|     |        | 6-707-715-01                |   | IC RH80536NC0171MSL86K (CM-DO 1.4)           |            |      | •       | •      | •       | •      |      | •      | •      | •     |        |       |       |   |               |
| ı   | 303    | 6-707-350-01                |   | IC HYS64T64020HDL-5-A(512MB)                 | •          | •    | •       | •      | •       | •      | •    | •      | •      | •     | •      |       |       |   | $\neg$        |
| - 1 |        | 6-707-504-01                |   | IC HYS64T128021HDL-5-À(1GB)                  |            |      | •       | •      | •       | •      |      | •      | •      | •     |        |       |       |   | $\neg$        |
|     |        | 6-707-352-01                |   | IC HYS64T32000HDL-5-A(256MB)                 |            |      | •       | •      | •       | •      |      | •      | •      | •     |        | •     | •     |   | $\neg$        |
|     | 320    | 1-789-095-21                | # | WIRELESS LAN CARD                            | •          |      | •       | •      | •       | •      |      |        |        |       |        |       |       |   |               |
|     |        | 1-761-864-25                | # | WIRELESS LAN CARD                            |            | •    |         |        |         |        |      |        |        |       |        |       |       |   |               |
| 1A] |        | 1-789-095-11                | # | WIRELESS LAN CARD                            |            |      |         |        |         |        | •    | •      | •      | •     |        |       |       |   | -             |
| ΙΑj |        | 1-761-864-15                | # | WIRELESS LAN CARD                            |            |      |         |        |         |        |      | •      | •      | •     |        |       |       |   | -             |
| ΙΑį |        | 1-761-864-34                | # | WIRELESS LAN CARD                            |            |      |         |        |         |        |      |        |        |       | •      | •     | •     |   | -             |





[MA]

- 1) The DIP switch setting, refer to page 4-17 "DIP switch".
- The CPU THERMAL PAD (Ref.328) cannot be re-used if it is removed once.
   When the FIN THERMAL MODULE (Ref.317) is removed, be sure to replace it with the new one.
- 3) When change the CPU (Ref.302), refer to "5-2 Replacing the CPU "in CHAPTER 5.
- 1) DIP スイッチの設定は、4-17頁「DIP Switch」を参照してください。
- 2) CPU THERMAL PAD (Ref.328) は、一度取り外したものを再利用することはできません。 FIN THERMAL MODULE (Ref.317) をはずした場合には、必ず新しいものを交換してください。
- 3) CPU (Ref.302) を交換する際は、CHAPTER 5、「5-2 CPU の交換」を参照してください。
- This parts list contains two different types of parts.
  The first type is the parts that are common to all models.
  The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (\*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(\*) がつくのは CTO モデルです。



•4) Ref.552 is a part that is only needed for Ref.534 A-1108-510-A, A-1108-509-A, and A-1109-275-A.

●4) Ref.552 は、Ref.534 A-1108-510-A, A-1108-509-A, A-1109-275-A のみに必要な部品です。

## B-1. Bottom

| Ref.No.                         | Part No.   |             | <u>Description</u>   |
|---------------------------------|--|-------------|--|
| 7<br>501<br>502<br>504<br>505   | 4-682-423-01<br>A-1058-406-A<br>A-1058-416-A<br>A-1094-551-A \$<br>A-1094-552-A \$ # |             | SE1 SPONGE BT CABLE(26P), FLEXIBLE FLAT CABLE, ODD EJECT COMPLETE PWB CNX-290 COMPLETE PWB IFX-378   |
| 506<br>507<br>508<br>509<br>510 | X-4626-658-4<br>4-682-454-01<br>4-682-455-01<br>4-682-460-01<br>4-682-457-01         |             | SE1P BOTTOM ASSEY SE1 15S BATT BUTTON SE1 15S BATT BUTTON3 SE1 15S DOOR DOCK SE1 BATT LOCK   |
| 511<br>512<br>513<br>514<br>515 | 4-683-040-01<br>4-682-443-01<br>4-682-444-01<br>4-682-445-01<br>4-682-456-01         | &<br>&      |  |
| 516<br>517<br>518<br>519<br>520 | 4-682-459-01<br>4-682-479-01<br>4-682-458-02<br>4-682-476-01<br>2-103-697-01         |             | SE1 LATCH BATT SPRING<br>SE1 EMI SPRING BATT<br>SE1 LATCH LEVER<br>SE1 SW BRACKET<br>SE1P HDD MYLAR  |
| 521<br>522<br>523<br>524<br>525 | 2-103-698-01<br>4-682-447-01<br>X-4626-721-1<br>X-4626-653-1<br>X-4626-720-1         | &<br>&<br>& | SE1 DIMM DOOR ASSY   |
| 526<br>527<br>535<br>536<br>538 | 2-025-132-01<br>4-682-466-01<br>4-682-580-01<br>4-682-581-01<br>4-682-568-01         | &<br>&      |  |
| 541<br>542<br>543<br>544<br>545 | 2-103-696-01<br>2-103-695-01<br>A-1094-549-A \$<br>1-865-674-11<br>4-682-462-01      |             | SE1P SHEET BLUETOOTH ANT<br>SE1P BATT MASK MYLAR B<br>COMPLETE PWB CNX-288<br>PWB(26P),FLEXIBLE PRINT<br>SE1 15S MODEM R                         |
| 547<br>550<br>551               | 2-067-843-01<br>2-159-787-01<br>2-583-811-01   |             | EMI SPRING HDD<br>SE1 SPONGE LENS<br>MYLAR SATA HDD BOARD  |
| B1<br>B2<br>B3<br>B5<br>B9      | 4-672-836-01<br>4-672-836-21<br>4-672-834-41<br>4-672-836-11<br>2-159-307-01         | <&><br><&>  | SCREW, M2 SPECIAL HEAD,EG GRIP<br>SCREW, M2 SPECIAL HEAD,EG GRIP<br>SCREW, +B EG GRIP<br>SCREW, M2 SPECIAL HEAD,EG GRIP<br>SCREW, M2.6+B EG GRIP |
| B11<br>B12<br>B18<br>B23<br>B24 | 4-672-839-01<br>4-672-840-01<br>4-672-834-21<br>3-254-029-11<br>4-672-834-71         |             | HEAD,M3 FLAT<br>SCREW, M2 TAPPING,FLAT HEAD<br>SCREW, +B EG GRIP<br>SCREW<br>SCREW,+B EG GRIP  |

|          |      |     |              |         |                                 |       |      |         | J      |         |        |      | Α      | М      |       |        | EU    |       |  |
|----------|------|-----|--------------|---------|---------------------------------|-------|------|---------|--------|---------|--------|------|--------|--------|-------|--------|-------|-------|--|
|          |      |     | . Part No.   |         | Description                     | A72PB | A62B | A72PS1* | A72S1* | A72PS2* | A72S2* | A690 | A600P* | A600B* | A600* | A397XP | A317S | A317M |  |
|          |      | 503 | A-1058-408-A |         | CABLE, WIRELESS MOUSE           | •     | •    | •       | •      | •       | •      |      | •      | •      | •     | •      | •     | •     |  |
|          |      | 528 | 4-682-449-01 |         | SE1 LENS PANEL CTO (W/WL,W/BT)  |       |      |         |        |         |        |      | •      | •      | •     | •      | •     | •     |  |
|          |      |     | 4-682-449-11 |         | SE1 LENS PANEL CTO(W/WL,No-BT)  | •     | •    | •       | •      | •       | •      | •    | •      | •      | •     |        |       |       |  |
|          |      | 529 | 4-683-065-01 |         | SE1P BUTTON COVER RF(W/W-Mouse) | •     | •    | •       | •      | •       | •      |      | •      | •      | •     | •      | •     | •     |  |
| ◬        | [MA] | 530 | 4-683-066-01 |         | SE1P PANEL RF CTO(No-W-Mouse)   |       |      |         |        |         |        | •    | •      | •      | •     |        |       |       |  |
|          |      | 531 | 4-682-582-01 |         | SE1P BUTTON RF(W/W-Mouse)       | •     | •    | •       | •      | •       | •      |      | •      | •      | •     | •      | •     | •     |  |
|          |      | 532 | 4-682-583-01 |         | SE1P SPRING RF KNOB(W/W-Mouse)  | •     | •    | •       | •      | •       | •      |      | •      | •      | •     | •      | •     | •     |  |
|          |      | 533 | 1-796-949-11 |         | USB RF MOUSE RECEIVER           | •     | •    | •       | •      | •       | •      |      | •      | •      | •     | •      | •     | •     |  |
|          |      | 534 | A-1105-612-A | \$<br># | HDD (100GB,HTS541010G9SA00)     | •     | •    | •       | •      | •       | •      | •    | •      | •      | •     |        | •     |       |  |
|          |      |     | A-1108-510-A | \$<br># | HDD(MHT2080-80GB)               |       |      | •       | •      | •       | •      |      | •      | •      | •     | •      |       | •     |  |
|          |      |     | A-1108-509-A | \$<br># | HDD(MHT2060-60GB)               |       |      | •       | •      | •       | •      |      | •      | •      | •     |        |       |       |  |
| Δ        | [MA] |     | A-1109-275-A | \$<br># | HDD(MHT2040-40GB)               |       |      |         |        |         |        |      | •      | •      | •     |        |       |       |  |
| $\Delta$ | [MA] | 539 | 1-805-554-11 |         | BLUETOOTH MODULE                |       |      |         |        |         |        |      | •      | •      | •     | •      | •     | •     |  |
| $\Delta$ | [MA] | 540 | A-1058-407-A |         | CABLE,BT ANTENNA                |       |      |         |        |         |        |      | •      | •      | •     | •      | •     | •     |  |
|          |      | 548 | 4-682-446-01 |         | SE1 SWICH W LAN(W/WL)           | •     | •    | •       | •      | •       | •      | •    | •      | •      | •     | •      | •     | •     |  |
|          |      | 552 | 2-583-812-01 |         | AL FOIL SATA HDD                |       |      | •       | •      | •       | •      |      | •      | •      | •     | •      |       | •     |  |
|          |      |     |              |         |                                 |       |      |         |        |         |        | [MA] | [MA]   | [MA]   | [MA]  | [MA]⊳  | [MA]⊳ | [MA]  |  |


- •2) Ref.503, 529, 531, 532, and 533 are parts for the models with a wireless mouse. **MA**
- •3) Ref.530 is a part for the models without a wireless mouse. **(MA)**
- •4) Ref.552 is a part that is only needed for Ref.534 A-1108-510-A, A-1108-509-A, and A-1109-275-A.
- ●1) Ref.539 と Ref.540 は、BULETOOTH 搭載モデル用の部品です。 ▲ [MA]
- ●2) Ref.503,529,531,532.533 は、Wireless-Mouse 付モデル用の部品です。 **△[MA]**
- ●3) Ref.530 は、Wirelass-Mouse が付かないモデル用の部品です。 **◇【MA】**
- ●4) Ref.552 は、Ref.534 A-1108-510-A, A-1108-509-A, A-1109-275-A のみに必要な部品です。
- This parts list contains two different types of parts.
   The first type is the parts that are common to all models.
   The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (\*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(\*) がつくのは CTO モデルです。


## D-1. Optical Drive


## **How to Use Parts Differently.**

This series of product uses the five diffrent types of the optical drive.

When replacing the optical drive, check the indication label of it, and use the same type of the optical drive. Each optical drive has different types of the bezel. For the how to identify the type of drive and the combination of the Bezel, refer to the details below.







## D-1. Optical Drive

| Ref.No. | Part No.     | <u>Description</u>             |
|---------|--------------|--------------------------------|
| 802     | 4-682-408-01 | SE1 CD BRACKET BACK            |
| 803     | 4-682-406-01 | SE1 CD BRACKET L               |
| 804     | 4-682-407-01 | SE1 CD BRACKET R               |
| 809     | 2-102-385-01 | SE1 GASKET ODD                 |
| 820     | A-1094-550-A | COMPLETE PWB CNX-289           |
| 821     | 4-682-950-01 | SE1 ODD BOARD MYLAR            |
| B1      | 4-672-836-01 | SCREW, M2 SPECIAL HEAD,EG GRIP |
| B5      | 4-672-836-11 | SCREW, M2 SPECIAL HEAD         |
| B17     | 4-671-538-01 | SCREW(M2x4), SPECIAL HEAD      |

|        |          |                     |          |          |                           |       |                |         | J      |         |        |          | Α      | M      |       |        | EU    |       |    | П        |
|--------|----------|---------------------|----------|----------|---------------------------|-------|----------------|---------|--------|---------|--------|----------|--------|--------|-------|--------|-------|-------|----|----------|
|        | Pof No   | o. Part No.         |          |          | Description               | A72PB | A62B           | A72PS1* | A72S1* | A72PS2* | A72S2* | A690     | A600P* | A600B* | A600* | A397XP | A317S | A317M |    |          |
|        | 810      | 1-797-066-11        | S        | #        | DVD+-RW(UJ-831BSX2-A)     | •     | •              | •       | •      | •       | •      | $\vdash$ |        |        |       |        |       |       | -+ | $\dashv$ |
| ∧ [MA] | 811      | 8-457-624-90        | <u> </u> | #        | DRIVE, DVD DW-D56A-V2     |       | <del>+</del> − | -       | _      |         |        | •        | •      | •      | •     | •      | •     | •     | -+ | $\dashv$ |
| 2.5    | 814      | 1-797-053-21        | \$       | #        | COMBO DRIVE(UJDA760)      |       | +              | •       | •      | •       | •      |          | •      | •      | •     |        |       |       | -+ | $\dashv$ |
|        | 815      | X-2024-227-1        | -        |          | SE2 PCC UJ830B DVD+-ŔW    | •     | •              | •       | •      | •       | •      |          |        |        |       |        |       |       | -  | $\dashv$ |
| ∧ [MA] | 816      | X-2024-036-1        |          |          | SE2 CD DW-D56A BEZEL ASSY |       | 1              |         |        |         |        | •        | •      | •      | •     | •      | •     | •     | -  | ┪        |
|        | 819      | X-2024-057-1        |          |          | SE2 UJDA-760 BEZEL ASSY   |       |                | •       | •      | •       | •      |          | •      | •      | •     |        |       |       |    | ┪        |
|        | B19      | 4-645-177-01        |          |          | SCREW(M1.7x3.5)           | •     | •              | •       | •      | •       | •      |          | •      | •      | •     |        |       |       |    | ┑        |
| •      | This nar | ts list contains tw | o differ | ent tyne | s of narts                |       | •              | -       | •      |         |        | [MA]     | [MA]   | [MA]   | [MA]  |        | [MA]⊳ | [MA]  | •  | _        |

- This parts list contains two different types of parts.
  The first type is the parts that are common to all models.
  The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (\*) is the CTO model.
- ●この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(\*)がつくのは CTO モデルです。

## L-1. LCD 17-inch WUXGA (Clear Black LCD) - Made by SH-1016 **ത്** B5 1017 Supplied with 1016 1013 1011 1021 **%** B5 1002 1020 1022 1004 `**%** B1 1057 1018-1006 M-1 > 1001 1008 **3**M-1 Supplied with 1014 B2 1006 **™** B5 **4** B-1 **1** M-1 1007 1019 1003 1008 **©** B-1 1015 1005 **୍ଷ** B5 Confidential **@** M-1


1012

## L-1. LCD 17-inch WUXGA (Clear Black LCD) - Made by SH-

| Part No.          |  | <u>Description</u>   |
|-------------------|--|--|
| 4-682-380-01      |  | SE1 COVER HINGE  |
| A-8119-991-A      |  | HARNESS, LCD FOR 17WUXGA   |
| X-4626-664-1      |  | SE1P BEZEL DISPLAY 17 ASM  |
| 4-682-397-01      | &  | SE1 CUSHION LCD SIDE   |
| 4-682-396-01      | &  | SE1 CUSHION LATCH  |
| 4-682-395-01      | &  | SE1 CUSHION LCD  |
| 4-682-398-01      | &  | SE1 COVER SCREW  |
| 4-682-388-01      |  | SE1 HOOK PLATE LCD 2   |
| 4-682-390-02      |  | HOOK LCD 15  |
| 2-024-790-01      |  | SE1 GASKET AU LVDS DISPLAY   |
| A-1062-138-A \$ # |  | LCD_UNIT_(2CFL-17WUXGA)(S)   |
| 4-682-578-01      |  | SE1P HINGE L AMS   |
| 4-682-577-01      |  | SE1P HINGE R AMS   |
| X-4626-663-1      |  | SE1P HOUSING DISPLAY 17 2 ASM  |
| 4-682-576-01      |  | SE1P LCD BRACKET L   |
| 4-682-575-01      |  | SE1P LCD BRACKET R   |
| 1-478-629-11      |  | INVERTER UNIT(2CFL-17W)  |
| 2-159-645-01      |  | SE1P INVERTER ADHESIVE   |
| 2-190-716-01      |  | SE1P HOUSING AL L  |
| 2-190-717-01      |  | SE1P HOUSING AL R  |
| 2-190-718-01      |  | SE1P HOUSING AL BTM  |
| 4-672-836-01      |  | SCREW, M2 SPECIAL HEAD,EG GRIP   |
| 4-672-836-21      |  | SCREW, M2 SPECIAL HEAD, EG GRIP  |
| 4-672-836-11      | <&>  | SCREW, M2 SPECIAL HEAD,EG GRIP   |
| 4-671-538-01      |  | SCREW(M2x4),SPECIAL HEAD   |
| 2-108-227-01      |  | SPECIAL FLAT HEAD  |
|                   | 4-682-380-01<br>A-8119-991-A<br>X-4626-664-1<br>4-682-397-01<br>4-682-396-01<br>4-682-398-01<br>4-682-398-01<br>4-682-398-01<br>4-682-390-02<br>2-024-790-01<br>A-1062-138-A<br>4-682-577-01<br>X-4626-663-1<br>4-682-577-01<br>1-478-629-11<br>2-190-718-01<br>2-190-718-01<br>4-672-836-01<br>4-672-836-11<br>4-672-836-11<br>4-671-538-01 | 4-682-380-01 A-8119-991-A X-4626-664-1 4-682-397-01 & 4-682-396-01 & 4-682-398-01 & 4-682-398-01 & 4-682-398-01 & 4-682-398-01 & 4-682-390-02 2-024-790-01 A-1062-138-A 4-682-578-01 4-682-578-01 4-682-577-01 X-4626-663-1 4-682-576-01 4-682-576-01 2-190-718-01 2-190-718-01 2-190-718-01 4-672-836-01 4-672-836-11 4-672-836-11 4-671-538-01 |

|                              |  |                           |     |         |        |      | I      | λM     |       | EU     |   |        |
|------------------------------|--|---------------------------|-----|---------|--------|------|--------|--------|-------|--------|---|--------|
|                              | Ref.No. Part No.                       | Description               | 000 | A72004* | A72S1* | A690 | A600P* | A600B* | A600* | A397XP |   |        |
| F                            | 1002 A-1058-425-A                      | CABLE, WL ANTENNA         |     | •       | •      | •    | •      | •      | •     | •      | H | -      |
| F                            | 1012 2-581-495-01                      | LABEL ID (J)              |     | •       |        |      | 1      | 1      |       |        |   | $\neg$ |
|                              | 2-583-683-01                           | LABEL ID (JCTO)           |     | -       | •      |      |        |        |       |        | П |        |
|                              | 2-583-683-11                           | LABEL ID (JCTO)           |     |         | •      |      |        |        |       |        |   |        |
| [MA]<br>[MA]<br>[MA]<br>[MA] | 2-581-496-01                           | LABEL ID (U)              |     |         |        | •    |        |        |       |        |   |        |
| [MA]                         | 2-583-680-01                           | LABEL ID (UCTO)           |     |         |        |      | •      |        |       |        |   |        |
| [MA]                         | 2-583-680-21                           | LABEL ID (UCTO)           |     |         |        |      |        | •      |       |        |   |        |
| [MA]                         | 2-583-680-11                           | LABEL ID (UCTO)           |     |         |        |      |        |        | •     |        |   |        |
| [MA]                         | 2-581-497-01                           | LABEL ID (E)              |     |         |        |      |        |        |       | •      |   |        |
|                              |  |                           |     |         |        |      |        |        |       |        |   |        |
| L                            |  |                           |     |         |        |      | _      | _      |       |        | ш |        |
| L                            | 1057 2-583-807-01                      | RH FERRITE CORE BRH8X12X4 |     | •       | •      | •    | •      | •      | •     | •      | ш |        |
|                              | This parts list contains two different |                           |     |         |        | [MA] | [MA]   | [MA]   | [MA]  | [MA]   |   |        |

- This parts list contains two different types of parts. The first type is the parts that are common to all models. The other type is the parts that are different depending on each model.
- This model that is accompanied by asterisk (\*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- ●機種名に(\*)がつくのは CTO モデルです。



# L-2. LCD 17-inch WXGA+ (Clear Black LCD) – Made by AU–

| Ref.No. | Part No.          |     | Description                     |
|---------|-------------------|-----|---------------------------------|
| 1001    | 4-682-380-01      |     | SE1 COVER HINGE                 |
| 1005    | 4-682-397-01      | &   | SE1 CUSHION LCD SIDE            |
| 1006    | 4-682-396-01      | &   | SE1 CUSHION LATCH               |
| 1007    | 4-682-395-01      | &   | SE1 CUSHION LCD                 |
| 1008    | 4-682-398-01      | &   | SE1 COVER SCREW                 |
| 1009    | 4-682-388-01      |     | SE1 HOOK PLATE LCD 2            |
| 1010    | 4-682-390-02      |     | HOOK LCD 15                     |
| 1011    | 2-024-790-01      |     | SE1 GASKET AU LVDS DISPLAY      |
| 1014    | 4-682-578-01      |     | SE1P HINGE L AMS                |
| 1015    | 4-682-577-01      |     | SE1P HINGE R AMS                |
| 1016    | X-4626-663-1      |     | SE1P HOUSING DISPLAY 17 2 ASM   |
| 1019    | 1-478-629-11      |     | INVERTER UNIT(2CFL-17W)         |
| 1020    | 2-159-645-01      |     | SE1P INVERTER ADHESIVE          |
| 1021    | 2-190-716-01      |     | SE1P HOUSING AL L               |
| 1022    | 2-190-717-01      |     | SE1P HOUSING AL R               |
| 1023    | 2-190-718-01      |     | SE1P HOUSING AL BTM             |
| 1051    | X-2024-399-1      |     | SE2P BEZEL DISPLAY 17 AU        |
| 1052    | A-1074-808-A      |     | HARNESS,LCD 17 WXGA             |
| 1053    | 2-176-382-01      |     | SE2P LCD BRACKET L              |
| 1054    | 2-176-383-01      |     | SE2P LCD BRACKET R              |
| 1055    | A-1087-141-A \$ # |     | LCD UNIT (17WXGA) (S)           |
| 1056    | 2-342-994-01      |     | SHIELD TAPE(AU17)               |
| B1      | 4-672-836-01      |     | SCREW, M2 SPECIAL HEAD,EG GRIP  |
| B2      | 4-672-836-21      |     | SCREW, M2 SPECIAL HEAD, EG GRIP |
| B5      | 4-672-836-11      | <&> | SCREW, M2 SPECIAL HEAD, EG GRIP |
| B17     | 4-671-538-01      |     | SCREW(M2x4),SPECIAL HEAD        |
| B22     | 2-108-227-01      |     | SPECIAL FLAT HEAD               |

|  |         |              |                           |      | J       |        |        | AM     |       | Е     | IJ    |
|--|---------|--------------|---------------------------|------|---------|--------|--------|--------|-------|-------|-------|
|  |         |              |                           | A62B | 472PS2* | A72S2* | A600P* | A600B* | A600* | A317S | A317M |
|  | Ref.No. | . Part No.   | Description               |      |         |        |        |        |       |       |       |
|  |         | A-1058-425-A | CABLE, WL ANTENNA         | •    | •       | •      | •      | •      | •     | •     | •     |
|  | 1012    | 2-581-495-11 | LABEL ID (J)              | •    |         |        |        |        |       |       |       |
|  |         | 2-583-683-21 | LABEL ID (JCTO)           |      | •       |        |        |        |       |       |       |
|  |         | 2-583-683-31 | LABEL ID (JCTO)           |      |         | •      |        |        |       |       |       |
| <u>∕</u> \$ [MA]   |         | 2-583-680-01 | LABEL ID (UCTO)           |      |         |        | •      |        |       |       |       |
| <u> </u>   |         | 2-583-680-21 | LABEL ID (UCTO)           |      |         |        |        | •      |       |       |       |
| <u>√</u> [MA]  |         | 2-583-680-11 | LABEL ID (UCTO)           |      |         |        |        |        | •     |       |       |
| MA<br>MA<br>MA<br>MA<br>MA   |         | 2-581-497-11 | LABEL ID (E)              |      |         |        |        |        |       | •     |       |
| MA     MA |         | 2-581-497-21 | LABEL ID (E)              |      |         |        |        |        |       |       | •     |
|  | 1057    | 2-583-807-01 | RH FERRITE CORE BRH8X12X4 | •    | •       | •      | •      | •      | •     | •     | •     |

This parts list contains two different types of parts.
 The first type is the parts that are common to all models.
 The other type is the parts that are different depending on each model.

- This model that is accompanied by asterisk (\*) is the CTO model.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- 機種名に(\*) がつくのは CTO モデルです。

## A-1. Accessories































| 2026 •1)         |
|------------------|
| Remote Commander |
|                  |
|                  |



|                  |          |              |                |   |       |      |         |        |               |        |               | A      | M      |       |        | EU    |       |   |
|------------------|----------|--------------|----------------|---|-------|------|---------|--------|---------------|--------|---------------|--------|--------|-------|--------|-------|-------|---|
|                  | Ref.No.  | Part No.     |                | Description                                       | A72PB | A62B | A72PS1* | A72S1* | A72PS2*       | A72S2* | A690          | A600P* | A600B* | A600* | A397XP | A317S | A317M |   |
|                  | △ 2001   | 1-479-114-11 | \$<br>&        | ADAPTOR, AC                                       |       |      | •       | •      | •             | •      |               | •      | •      | •     | •      |       | •     |   |
|                  |          | 1-478-037-33 | \$<br>&        | ADAPTOR, AC                                       | •     | •    | •       | •      | •             | •      | •             | •      | •      | •     |        | •     |       |   |
|                  |          | A-1062-155-A | \$<br>&        | BATTERY 9130PA SNT (J) (S)                        | •     | •    | •       | •      | •             | •      |               |        |        |       |        |       |       |   |
| MA]              |          | A-1062-142-A | \$<br>&        | BATTERY 9130 (U)(S)                               |       |      |         |        |               |        | •             | •      | •      | •     |        |       |       |   |
| ⊼ [MA]           | <u> </u> | A-1062-143-A | \$<br>&        | BATTERY 9130 (E)(S)                               |       |      |         |        |               |        |               |        |        |       | •      | •     | •     | $-\!$ |
|                  |          |              |                |   |       |      |         | _      | -             | _      | _             |        |        |       |        |       |       | $-\!\!\!\!\!+$  |
| A [MA]           | 1 1 2002 | 1-829-237-21 | &              | CORD. POWER                                       |       |      |         | -      | $\rightarrow$ | -      | •             | •      | •      | •     |        |       |       | $-\!\!\!+\!\!\!\!-$   |
| <u> </u>         |          | 1-790-732-32 | - <del>«</del> | CORD, POWER                                       |       |      | •       | •      | •             | •      | •             | •      | •      | •     |        |       |       | $-\!\!\!+\!\!\!\!-$   |
| /∖ [MA]          |          | 1-823-935-51 | <u>&amp;</u>   | CORD, AC POWER(GB)                                |       |      |         | -      | -             | •      | $\dashv$      |        |        |       | •      | •     | •     | +   |
| 212 [118 4]      |          | 1-829-239-11 | - &            | CORD. F TERMINAL WITH RF                          | •     | •    | •       | •      | •             | •      | •             | •      | •      | •     | Ť      | _     | -     |   |
|                  | 2000     | 1 020 200 11 |                | CORD, I TERMINAL WITH I                           | Ť     |      |         | -      | Ť             | _      | _             | _      |        | _     |        |       |       | -   |
|                  | 2007     | 1-827-160-21 | &              | POWER-SUPPLY CORD                                 | •     | •    |         | _      | -             | _      | $\neg$        |        |        |       |        |       |       | -   |
| <u></u> [MA]     | 1        | 1-827-481-21 | &              | POWER-SUPPLY CORD                                 |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
| ⊼ [MA]           | 2008     | 1-816-429-12 | &              | PHONE PLUG (GB)                                   |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
|                  | 2009     | A-1091-713-A | &              | ASSY SPEAKER FW                                   | •     | •    | •       | •      | •             | •      | •             | •      | •      | •     |        | •     |       |   |
|                  | 2010     | -            |                | PORT REPLICATOR                                   | •     | •    | •       | •      | •             | •      | •             | •      | •      | •     |        | •     |       |   |
|                  |          | 1-478-615-11 | &              | MEMORY CARD ADAPTER                               | •     | •    | •       | •      | •             | •      |               |        |        |       |        |       |       |   |
|                  |          | 1-796-824-32 | &              | MOUSE (SLV)                                       | •     | •    | •       | •      | •             | •      |               | •      | •      | •     | •      | •     | •     |   |
|                  |          | 1-478-688-11 | &              | REMOTE COMMANDER (RM-VC10)                        | •     | •    | •       | •      | •             | •      |               |        |        |       |        |       |       |   |
| <u></u> [MA]     | 2024     | 1-478-969-11 | &              | REMOTE COMMANDER (RM-VC10E)                       |       |      |         |        |               |        |               |        |        |       |        | •     |       | $\dashv$  |
| A (N.4.A.)       | 1 0000   | 4 470 400 44 | 0              | DEMOTE COMMANDED (DM ) (C4011)                    |       |      |         |        | _             | _      | _             | _      |        | _     |        |       |       | $-\!\!\!+\!\!\!\!-$   |
| <u></u> [MA]     |          |              | &<br>&         | REMOTE COMMANDER (RM-VC10U) OVERALL DA ASSY ,MAIN | •     | •    | •       | •      | •             | •      | •             | •      | •      | •     |        |       |       | -   |
|                  |          | 2-584-072-01 | - &<br>- &     | MANUAL (XP), INSTRUCTION                          | -     |      | •       |        | •             | •      |               |        |        |       |        |       |       | $-\!\!\!+\!\!\!\!-$   |
| ∕à [MA]          | ı -      | 2-585-226-01 | <u>&amp;</u>   | QUICK START (A) (EN) (CDS)                        | •     | •    | •       | •      | •             | •      | •             | _      | _      |       |        |       |       | $-\!\!+\!\!-$   |
| 太 [MA]           |          | 2-585-784-01 | - &            | QUICK START (A) (SD)                              | _     |      |         | -      | -+            | -      | -             | •      | •      | •     |        |       |       | $-\!\!\!+\!\!\!\!-$   |
| 723 [148 4]      | y -      | 2-303-704-01 | и.             | QUICK START (A) (OD)                              |       |      |         | -      | -             | -      | $\rightarrow$ | _      | _      | _     |        |       |       | $-\!\!\!+\!\!\!\!-$   |
|                  |          |              |                |   |       |      |         |        | _             | _      | _             |        |        |       |        |       |       | -   |
|                  |          |              |                |   |       |      |         |        |               |        |               |        |        |       |        |       |       |   |
| <u></u> [MA]     |          | 2-583-969-11 | &              | HW SPECS, (E) A GB,NL,ES,PT                       |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
| <u>∧</u> [MA]    |          | 2-583-969-61 | &              | HW SPECS (E) A NL.BE                              |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
| ⚠ [MA]<br>⚠ [MA] |          | 2-583-970-11 | &              | HW SPECS (E) B NL                                 |       |      |         |        |               |        |               |        |        |       | •      |       |       |   |
| <u></u> [MA]     |          | 2-583-970-21 | &              | HW SPECS (E) B NL                                 |       |      |         |        |               |        |               |        |        |       | •      |       |       |   |
| [MA]             |          | 2-583-969-21 | &              | HW SPECS (E) A DE,CH                              |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
| <u>∧</u> [MA]    |          | 2-583-969-31 | &              | HW SPECS (E) A FR,BE,CH                           |       |      |         |        |               |        |               |        |        |       | •      | •     | •     |   |
| [MA]             |          | 2-583-969-41 | &              | HW SPECS (E) A IT,CH                              |       |      |         |        | _             |        |               |        |        |       | •      | •     | •     | $\dashv$  |
| A [MA]           |          | 2-583-969-51 | &              | HW SPECS (E) A SS                                 |       |      |         |        | _             |        |               |        |        |       | •      | •     | •     | $\dashv$  |
| MA]              |          | 2-583-969-81 | &              | HW SPECS (E) A SE                                 |       |      |         |        | -             |        | _             |        |        |       | •      |       |       | $-\!$ |
| <u>∧</u> [MA]    | .]       | 2-583-969-91 | &              | HW SPECS (E) A (PT)                               |       |      |         |        |               |        |               |        | $\Box$ | _     | •      | _     | igsim |   |
|                  |          |              |                |   |       |      |         |        |               |        | [MA]          | [MA]   | [MA]   | [MA]  | [MA]   | [MA]⊳ | [MA]⊳ |   |

- •1) The Ref.2005,2009,2010,2011,2023,2024 and 2026 are included only in the models supplied with the Port Replicator.
- •2) Ref.2027 is packed only with the models equipped with Pentium M. (Refer to 1-1.SPECIFICATION, and 1-2. CTO INFORMATION.)
- ●1) Ref.2005,2009,2010,2011,2023,2024,2026 は、Port Replicator 同梱機種のみについてきます。
- ●2) Ref.2027 は、Pentium M 搭載機種のみに同梱されます。(1-1.SPECIFICATION ,1-2. CTO INFORMATION をご参照ください)
- This model that is accompanied by asterisk (\*) is the CTO model.
- 機種名に(\*)がつくのは CTO モデルです。

A-2. Accessories



## A-2. Accessories

2162 2-148-338-01

| Ref.No. | Part No.        |   | Description                   |
|---------|-----------------|---|-------------------------------|
| 2101    | X-4626-667-1    |   | SUB HOUSING UPPER BPR ASSY    |
| 2102    | 4-682-689-01    |   | BPR MYLAR FOOT                |
| 2103    | 4-682-693-01    |   | BPR CAP BOSS DOCK CONN        |
| 2104    | 4-682-694-01    |   | BPR BRACKET ARM TRAY          |
| 2105    | 4-682-695-01    |   | BPR HOOK FRONT                |
| 2103    | 4-002-093-01    |   | BENTIOORTHON                  |
| 2106    | 4-682-697-01    |   | BPR ARM SLIDE HOOK YOKO       |
| 2107    | 4-682-698-01    |   | BPR KNOB HOOK RELEASE         |
| 2108    | 4-682-699-01    |   | BPR KNOB HOOK RELEASE BOTTON  |
| 2109    | 4-682-700-01    |   | BPR PIN GND                   |
| 2110    | X-4626-672-1    |   | SUB HOUSING TRAY BPR ASSY     |
|         |                 |   |                               |
| 2111    | 4-682-721-01    |   | BPR CUSHION REAR              |
| 2112    | 4-682-720-01    | & |                               |
| 2113    | 2-048-435-01    |   | BPR MYLAR FPC                 |
| 2114    | A-1058-415-A    |   | HARNESS, DC                   |
| 2115    | A-1103-180-A \$ |   | COMPLETE PWB CNX-271          |
| 2116    | 4-682-690-01    |   | BPR PLATE DOCK CONN UPPER     |
| 2117    | 4-682-691-01    |   | BPR PLATE DOCK CONN BOTTOM    |
| 2117    | 2-048-436-01    |   | BPR MYLAR SHIELDING           |
| 2119    | X-2021-564-1    |   | BPR ASSYSUB CAM SLIDE HOOK    |
| 2119    | 2-048-437-01    |   | BPR SPONGE CAM SLIDE HOOK     |
| 2120    | 2-048-437-01    |   | BPR SPONGE CAM SLIDE HOOK     |
| 2121    | 4-682-709-01    |   | BPR ARM TRAY PIN              |
| 2122    | 4-682-712-01    |   | BPR BRACKET DC                |
| 2124    | 4-682-708-01    |   | BPR LIGHT GUIDE LED           |
| 2125    | 4-682-714-01    |   | BPR SPRING TRAY R             |
| 2126    | 4-682-715-01    |   | BPR SPRING TRAY L             |
|         |                 |   |                               |
| 2128    | X-4626-669-1    |   | SUB HOUSING BOTTOM BPR ASSY   |
| 2129    | 4-682-703-01    | & | BPR RUBBET FOOT               |
| 2130    | 2-048-440-01    |   | APR MYLAR B2B CONNECTOR       |
| 2132    | X-4626-671-1    |   | SUB FRAME BPR ASSY            |
| 2133    | 4-682-710-01    |   | BPR COVER RIGHT HOUSING UPPER |
| 2134    | 4-682-711-01    |   | BPR COVER LEFT HOUSING UPPER  |
| 2135    | A-1058-418-A    |   | PWB (60P), FLEXIBLE PRINT A   |
| 2136    | A-1058-419-A    |   | PWB (60P), FLEXIBLE PRINT B   |
| 2137    | A-1058-420-A    |   | CABLE, ETHER                  |
| 2140    | 4-682-728-01    |   | APR COVER BRACKET D-SUB-1     |
| 2140    | 4-002-720-01    |   | AFTI COVER BRACKET D-30B-1    |
| 2141    | 4-682-729-01    |   | APR COVER BRACKET D-SUB-2     |
| 2142    | 2-048-439-01    |   | BPR ENFORCE PLATE             |
| 2143    | 2-103-312-01    |   | MYLAR TOP SHIELD R            |
| 2145    | 2-103-314-01    |   | MYLAR 34x40                   |
| 2147    | 2-103-316-01    |   | GASKET 7x10x2                 |
| 04.40   | 0.400.047.04    |   | ANY AD LICON FRONT            |
| 2148    | 2-103-317-01    |   | MYLAR HOOK FRONT              |
| 2150    | 2-103-318-01    |   | APR FOIL AL 6x24              |
| 2151    | A-1102-188-A \$ |   | COMPLETE PWB IFX-312          |
| 2160    | 2-048-434-01    |   | BPR MYLAR BRACKET ARM TRAY    |
| 2161    | 2-103-313-01    |   | BPR MYLAR TOP SHIELD L        |
|         |                 |   |                               |

BPR SPONGE USB 2 PORT

| Ref.No. | Part No.     | <u>Description</u>         |
|---------|--------------|----------------------------|
| B31     | 4-635-966-01 | SCREW (HEX)                |
| B32     | 4-671-504-11 | <&> SCREW,TAPPING+P2.6     |
| B33     | 3-906-376-01 | SCREW(2.6x6)               |
| B34     | 4-639-112-31 | SCREW M2X4                 |
| B35     | 2-103-677-01 | T3X8L, (I) B-NI            |
| B36     | 4-641-726-21 | <&> SCREW(M2),SPECIAL HEAD |
| B37     | 4-671-538-01 | SCREW(M2x4),SPECIAL HEAD   |
| B38     | 4-635-301-11 | SCREW M3X4                 |

|                     |      | Pof No. | Part No.     |    | Description                    | J-PR | U-PR | E-PR     |               |
|---------------------|------|---------|--------------|----|--------------------------------|------|------|----------|---------------|
|                     |      |         | A-1103-179-A | \$ | COMPLETE PWB CNX-250A          | •    | •    | •        | $\vdash$      |
|                     |      | 2121    | A-1103-173-A | Ψ  | COMPLETE FWB CNX-230A          |      | _    | _        | <u> </u>      |
|                     |      | 2131    | X-4626-673-1 |    | SUB COVER IO AV1 APR1 ASSY     | •    | •    | •        | $\vdash$      |
|                     |      |         | 2-103-240-01 |    | MYLAR RCA 1PIN                 | •    | •    | •        |               |
|                     |      |         | 4-680-501-01 |    | RF.CONN WASHER                 | •    | •    |          |               |
| AD                  |      | 2152    | A-1103-181-A | \$ | COMPLETE PWB ENX-29(J)         | •    |      |          |               |
| <b>A</b>            | [MA] |         | A-1103-771-A | \$ | COMPLETE PWB ENX-29(Ú)         |      | •    |          |               |
| $\overline{\wedge}$ | ľΜΑΪ |         | A-1081-799-A | \$ | COMPLETE PWB ENX-34            |      |      | •        |               |
| _                   |      | 2153    | 4-682-722-01 |    | APR BRACKET TUNER              | •    | •    |          | $\overline{}$ |
|                     |      | 2154    | 4-680-482-01 |    | RF CONN,NUT                    | •    | •    |          | $\overline{}$ |
|                     |      | 2163    | 2-148-335-01 |    | APR THERMAL PAD TUNER BIG      | •    | •    |          | $\overline{}$ |
|                     |      | 2164    | 2-148-336-01 |    | APR THERMAL PAD TUNER SIDE     | •    | •    |          |               |
|                     |      | 2165    | X-2022-558-1 |    | ASSY SUB HEATSINK TUNER        | •    | •    |          | $\Box$        |
|                     |      | 2166    | 2-148-337-01 |    | APR ADHESIVE HEATSINK TUNER MO | •    | •    |          | $\Box$        |
| $\Delta$            | [MA] |         | X-2024-177-1 |    | APR SUB FAN BRACKET ASSY       |      |      | •        | $\Box$        |
| $\Delta$            | [MA] | 2168    | 2-318-497-01 |    | APR ADHESIVE FAN BRACKET       |      |      | •        | $\Box$        |
| $\Delta$            | [MA] | 2169    | A-1081-380-A |    | UDQFUMH07-AS DC FAN 105MM      |      |      | •        |               |
| $\Delta$            | [MA] |         | 2-345-931-01 |    | EPR MYLAR TUNER                |      |      | •        |               |
| $\triangle$         | [MA] | 2171    | 2-318-499-01 |    | EPR BRACKET TUNER              |      |      | •        |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      |          |               |
|                     |      |         |              |    |                                |      |      | ليا      |               |
|                     |      |         |              |    |                                |      | ◬    | $\Delta$ |               |


- The destination is shown in the list of 4-1 for the Port Replicator.

  Please refer to list shown in the below.
- ●ポートリプリケーターの仕向けは、4-1の一覧表を参照ください。


## **DIP Switch**


The DIP switch setting is following table.

DIPスイッチの設定は下の表をご参照ください。



#### [FOR CTO MODEL]





The DIP switch setting is different depending the types of LCD. Set the DIP switch of the CTO model in accordance with the [FOR CTO MODEL].

DIP スイッチの設定は、LCD の種類によって異なります。 CTO モデルは、【FOR CTO MODEL】の表に従って DIP スイッチを設定してください。


## CHAPTER 5. **OTHERS**

## 5-1. The barcode label


The hatched portion of the barcode label is used as the repair data.

バーコードラベルの網掛け部は、修理データとして使用しています。


[ MBX-128 Board ] (Side A)



[ IFX-378 Board ] (Side B)



[ HDD ] (Made by Hi) (Bottom)



Α : Parts No.


В : Serial No. : Revision No. C D : Product code : Maker Barcode

: Global User ID (iLink)


G : Mac Address : Barcode

[ MBX-128 Board ] (Side B)


[ Modem Card ]




[ LCD Unit ] (Rear)




[ Wireless LAN Card ]






[ Optical Drive ] (Top)



[ Port Replicator ] (Rear)




Confidential

## 5-2. Replacing the CPU


## 1. Removing the CPU

- ① Insert a flat-blade screwdriver into the notch as shown in the illustration and rotate it so that the protrusion comes to the lock release position.
- 2 Pull the CPU gently upward to lift it out of the CPU socket.



## 2. Installing the CPU

- ① Align the triangle reference mark of the CPU with that of the CPU socket and insert all the pins of the CPU to the corresponding holes of the CPU socket.
- While pressing the two positions marked by O, insert the flat head (-) screwdriver into the specified position and rotate the screwdriver to the LOCK position.



### NOTE:

Rotate a flat-blade screwdriver to the lock position securely. If not, the operation of the CPU may become unstable.



## List of VGN-A Series (As of January, 2005)

| Service Manual | Model Name  |            |            |           |
|----------------|-------------|------------|------------|-----------|
| Part No.       | J           | АМ         | EU         | AO        |
|                | VGN-A50B    | VGN-A130*  | VGN-A115B  | VGN-A11C  |
|                | VGN-A60B    | VGN-A130P* | VGN-A115S  | VGN-A13CP |
|                | VGN-A60PS*  | VGN-A170*  | VGN-A117S  | VGN-A15CP |
|                | VGN-A60S*   | VGN-A170P* | VGN-A195EP | VGN-A15GP |
| 9-876-367-XX   | VGN-A70P    | VGN-A190   | VGN-A195HP | VGN-A15LP |
| 0 0/0 00/ 700  | VGN-A70PS*  |            | VGN-A197VP | VGN-A17GP |
|                | VGN-A70S*   |            | VGN-A197XP | VGN-A17LP |
|                |             |            |            | VGN-A17SP |
|                |             |            |            | VGN-A17TP |
|                |             |            |            | VGN-A19CP |
|                |             | VGN-A140*  | VGN-A115M  | VGN-A17CP |
|                |             | VGN-A140B* | VGN-A115Z  | VGN-A19GP |
| 9-876-374-XX   |             | VGN-A140P* |            | VGN-A19LP |
|                |             | VGN-A150   |            | VGN-A19SP |
|                |             | VGN-A160   |            | VGN-A19TP |
|                |             | VGN-A190F  |            |           |
|                | VGN-A51PS1* | VGN-A230*  | VGN-A215M  | VGN-A21C  |
|                | VGN-A51PS2* | VGN-A230B* | VGN-A215Z  | VGN-A23CP |
|                | VGN-A51S1*  | VGN-A230P* | VGN-A217M  | VGN-A29CP |
|                | VGN-A51S2*  | VGN-A240*  | VGN-A217S  | VGN-A29GP |
|                | VGN-A61B    | VGN-A240B* | VGN-A295HP | VGN-A29LP |
|                | VGN-A71PS*  | VGN-A240P* | VGN-A297XP | VGN-A29SP |
| 9-876-387-XX   | VGN-A71S*   | VGN-A250   |            | VGN-A29TP |
|                |             | VGN-A260   |            |           |
|                |             | VGN-A270*  |            |           |
|                |             | VGN-A270B* |            |           |
|                |             | VGN-A270P* |            |           |
|                |             | VGN-A290   |            |           |
|                |             | VGN-A290F  |            |           |

| Service Manual | Model Name   |   |                                      |    |  |  |
|----------------|--|---|--------------------------------------|----|--|--|
| Part No.       | J  | АМ  | EU                                   | AO |  |  |
| 9-876-401-XX   | VGN-A62B<br>VGN-A72PB<br>VGN-A72PS1*<br>VGN-A72PS2*<br>VGN-A72S1*<br>VGNA72S2* | VGN-A600*<br>VGN-A600B*<br>VGN-A600P*<br>VGN-A690 | VGN-A317M<br>VGN-A317S<br>VGN-A397XP |    |  |  |

\* : CTO Model
: Additional Models

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部、または全部について、無断で データの複製、複写、転載することを禁じます。

\*: CTO Model

## **Revision History**

| Suffix | Ver.     | Date       | Contents  | QM No.      |
|--------|----------|------------|---|-------------|
| -01    | Ver.1    | 2004.12.27 | First Edition   |             |
| -02    | Ver.2    | 2005.01.13 | Front Page (Model Line Up), Page 3, Page 1-2, Page 4-1, Page 4-3, Page 4-5_9, | N2004_141AK |
|        |          |            | Page 4-11, Page 4-13_17, Back Cover   |             |
| -03    | Ver.3    | 2005.01.24 | Front Page (Model Line Up), Page 3, Page 1-1, Page 1-5, Page 1-6, Page 4-1,   | N2004_148AK |
|        |          |            | Page 4-1_3, Page 4-5_7, Page 4-9, Page 4-11, Page 4-13_17, Back Cover         |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        |          |            |   |             |
|        | < Remarl | ks >       |   |             |
|        |          |            |   |             |
|        |          |            |   |             |